

Operation of your Hot Tub Cinema (The Den only)



Caution the laser projector is very bright, do not look directly into the light beam. It is important to follow these steps carefully to avoid damage and or injury. The projector works best in dark conditions however it will still operate in daylight. If you are unsure on the operation please ask a member of the team for a demonstration before use.

1. Pull down projector screen to the bottom hook provided
2. Switch on the projector using the right switch on the pergola leg this will turn on the projector and speakers (you may hear a click on the speakers as they switch on this is normal)
3. Using the remote provided (black) navigate to the content you wish to watch (do not remove the remote from the waterproof bag – water damage caused because of its removal will be charged) – if you require new batteries please ask a team member for assistance
4. Once you are finished please ensure you log out of your account(s)
5. Return the remote to its provided hook
6. Switch off the projector by the switch (if the projector is left on for a prolonged period whilst not in use this can cause damage)
7. Return the screen to the stowed position by gently pulling down to release the catch – please release screen slowly and don't let go until fully inside the roller

Please;

Do not adjust the projector settings

Do not leave the projector on after use

Do not take the remote out of the waterproof bag

Be considerate of noise levels especially in the evening.